

Steinberg TOOLS for CI2 Installation Guide

ATTENTION

NOTICE

- This software and Installation Guide are the exclusive copyrights of Yamaha Corporation.
- Copying of the software or reproduction of this Installation Guide in whole or in part by any means is expressly forbidden without the written consent of the manufacturer.
- Steinberg/Yamaha makes no representations or warranties with regard to the use of the software and documentation and cannot be held responsible for the results of the use of this Installation Guide and the software.
- Future upgrades of application and system software and any changes in specifications and functions will be announced at the following website.
http://service.steinberg.de/goto.nsf/show/supportupdates_ci2_gb
http://service.steinberg.de/goto.nsf/show/supportupdates_ci2plus_gb
- Steinberg and Cubase are the registered trademarks of Steinberg Media Technologies GmbH.
- Windows is the registered trademark of Microsoft® Corporation.
- Apple, Mac and Macintosh are trademarks of Apple Inc., registered in the U.S. and other countries.
- The company names and product names in this manual are the trademarks or registered trademarks of their respective companies.
- Copying of the commercially available musical data including but not limited to MIDI data and/or audio data is strictly prohibited except for your personal use.

What is TOOLS for CI2?

TOOLS for CI2 consists of two software components: Yamaha Steinberg USB Driver and Steinberg CI2 Extension. Yamaha Steinberg USB Driver enables communication between the CI2/CI2+ and your computer. Using Steinberg CI2 Extension, you can link the CI2/CI2+ with a Cubase version which supports the Link functions between both of them. The TOOLS for CI2 Installer installs these two software components.

NOTE

- For information about Cubase versions that are compatible with the Link function, check the web site below.
http://service.steinberg.de/goto.nsf/show/supportupdates_ci2_gb
http://service.steinberg.de/goto.nsf/show/supportupdates_ci2plus_gb

Software Installation

Follow the steps below to install the software.

NOTE

- You are only permitted to use this software pursuant to the terms and conditions of the “License Agreement” shown during the installation.
- If the same software components have already been installed in your computer, you can use the same procedure as described in the Installation instructions here to update the software.

Windows


Preparation

If the following warning messages appear during the installation, click [Continue Anyway], [Yes], or [Install].

Example warning message on Windows XP



Example warning messages on Windows Vista/Windows 7



Installation

- 1 Turn off the computer.**
- 2 Disconnect all USB devices other than the mouse and keyboard from the computer.**
- 3 Start the computer and log on to the Administrator account.**
- 4 Double-click “setup.exe” in the compressed file (you have downloaded).**
- 5 Follow the on-screen instructions to install the software.**
Install the following software in order.
 - Yamaha Steinberg USB Driver
 - Steinberg CI2 Extension
- 6 When installation has been completed, click [Finish].**
If a window requiring you to restart your computer appears, follow the on-screen instructions and restart the computer.

Device Connection

- 7 Connect the device directly to the computer by using the included USB cable.**
Make sure to not connect it to a USB hub.
Windows XP:
The “Found New Hardware Wizard” window appears. Go on to step 8.
Windows Vista/Windows 7:
Go on to step 11.
- 8 If the “Can Windows connect to Windows Update to search for software?” message appears in the middle of the window, select “No, not this time” then click [Next].**
- 9 Confirm that the “Install the software automatically” has been selected then click [Next].**
- 10 When the installation has been completed, click [Finish].**

Confirmation of Installation

11 Open the “Device Manager” window as follows.

Windows XP:

[Start] → [Control Panel] → ([Performance and Maintenance]) → [System] → [Hardware] tab → [Device Manager]

Windows Vista/Windows 7:

[Start] → [Control Panel] → ([Hardware and Sound]) → [Device Manager]

12 Click on the [+] mark or [>] mark next to “Sound, video and game controllers.”

13 Confirm that the device name is listed.

Installation of the TOOLS for CI2 is now completed.

Mac

Installation

- 1 Turn off the computer.
- 2 Disconnect all USB devices other than the mouse and keyboard from the computer.
- 3 Start the computer and log in to the Administrator account.
- 4 Double-click “TOOLS for CI2.mpkg” in the compressed file (you have downloaded).
- 5 Follow the on-screen instructions to install the software.
- 6 When installation has been completed, click [Restart] to restart the computer.

Device Connection

- 7 Connect the device directly to the computer by using a USB cable.
Make sure to not connect it to a USB hub.

Confirmation of Installation

- 8 Open the “Audio MIDI Setup” window as follows.
[Macintosh HD] → [Applications] → [Utilities] → [Audio MIDI Setup]
- 9 Confirm that the device name is listed in the following.

Mac OS X 10.5:
In “Properties For:”

Mac OS X 10.6/10.7:
In the left column

Installation of the TOOLS for CI2 is now completed.

Uninstalling the Software

To uninstall TOOLS for CI2, you must remove the following two software components.

- Yamaha Steinberg USB Driver
- Steinberg CI2 Extension

Windows

1 Disconnect all other USB devices except mouse and keyboard from the computer.

2 Log on to the Administrator account.

Exit any open applications and close all open windows.

3 Open the window for the uninstall operation as follows.

Windows XP:

From the Start menu, select ([Settings] →) [Control Panel] → [Add or Remove Programs] to display the Add or Remove Programs panel. Click “Change or Remove Programs” located in the upper left.

Windows Vista/Windows 7:

From the Start menu, select [Control Panel] → [Uninstall a program] to call up the “Uninstall or change a program” panel.

4 Select “Yamaha Steinberg USB Driver,” “Steinberg CI2 Extension” from the list.

5 Uninstall them as follows.

Windows XP:

Click [Change/Remove] / [Remove].

Follow the on-screen instructions to remove the software.

Windows Vista/Windows 7:

Click the [Uninstall] / [Uninstall/Change].

If the “User Account Control” window appears, click [Continue] or [Yes].

Follow the on-screen instructions to remove the software.

Mac

Removing Yamaha Steinberg USB Driver

Remove the following folders and files from the boot disk (usually Macintosh HD).

NOTE

- If the folders below are not displayed in the Finder, select [Go to Folder...] under the [Go] menu of Finder, input the folder locations, and then click [Go].

/System/Library/Extensions

YamahaSteinbergUSBAudio.kext

/Applications/Yamaha/USBDriver/

Yamaha Steinberg USB Control Panel.app

/Library/PreferencePanes/

Yamaha Steinberg USB.prefPane

/Library/Preferences/

com.yamaha.YamahaSteinbergUSBDriver.plist

/Library/Audio/MIDI Drivers/

YamahaSteinbergUSBMIDI.plugin

/Library/Audio/MIDI Devices/Yamaha/Images/

USB_1500.tiff

USB_1502.tiff

USB_1503.tiff

USB_1506.tiff

USB_1507.tiff

/Library/Receipts/

YamahaSteinbergUSBAudioDriver.pkg

YamahaSteinbergUSBControlPanel.pkg

YamahaSteinbergUSBDriverplist.pkg

YamahaSteinbergUSBMIDIPlugIn.pkg

YamahaSteinbergUSBMIDIIcon.pkg

YamahaSteinbergUSBPrefPane.pkg

Removing Steinberg CI2 Extension

Remove the following folders and files from the boot disk (usually Macintosh HD).

NOTE

- If the folders below are not displayed in the Finder, select [Go to Folder...] under the [Go] menu of Finder, input the folder locations, and then click [Go].

/Library/Application Support/Steinberg/Components/
ci2_extension_u.bundle

/Library/Application Support/Yamaha/
InteractiveRecording

/Library/Receipts/
Steinberg CI2 Extension.pkg