

YAMAHA Steinberg USB Driver V1.10.0b.1 for Windows

- This is a public beta driver which is expected to solve the issue(s) as below:
 - Audio dropout issues which are seen on specific environments
- For those who are not experiencing such issues, it is not recommended to use this driver at this moment.
- Since this is a beta driver, please use it at your own risk.
- Beta testing period is until about the end of November 2017. After confirming the validity an official driver will be released.

About installation / uninstallation

- Since this is a beta driver, update from / to an official version may not work properly.
Please uninstall the existing Yamaha Steinberg USB Driver from “Programs and Features” in the Control Panel manually before installing this driver, and also uninstall this driver manually before installing any official driver.

About the functions

- This driver has some functions temporarily for testing purpose as below:
 - Error detecting function
“Error Info” tab will be seen on the Yamaha Steinberg USB Driver Control Panel.
 - Audio engine setting function
On “Advanced” tab on the Yamaha Steinberg USB Driver Control Panel, there is “ISO Extra Buffer” setting. “Auto” is the default and should be suitable for most of the environments, but users can also set this manually. Large buffer size will increase stability, but also increase the latency.

Known issues

- [POWER] indicator on UR242 or UR44 would flash continuously after starting up the PC with Windows 10, even if the UR hardware and the driver are ready. In this case all other functions of the UR will work without any problem.

YAMAHA Steinberg USB Driver V1.10.0b.1 for Windows

- これは、下記のような問題への対応を目的としたテスト用ベータ版ドライバーです。
 - 特定の環境で発生する、音声の途切れやノイズ
- 上記のような問題でお困りのユーザー以外にはご使用をお勧めしません。
- 本ドライバーはベータ版ですので、ご使用は自己責任にてお願いいたします。
- ベータテストの期間は 2017 年 11 月末頃までを予定しています。ドライバーの有用性が確認出来次第、正式版ドライバーをリリース予定です。

インストール / アンインストールについて

- 本ドライバーはベータ版ですので、正式版ドライバーからのアップデート、および正式版ドライバーへのアップデートが正常に行われない場合があります。
本ドライバーをインストールする前に、コントロールパネルの「プログラムと機能」から既にインストールされている Yamaha Steinberg USB Driver を手動でアンインストールしてください。また、他の正式版ドライバーをインストールする前には同様に本ドライバーをコントロールパネルの「プログラムと機能」から手動でアンインストールしてください。

機能について

- 本ドライバーにはベータテストのための特別機能がいくつかあります。
 - エラー検知機能
コントロールパネルの“Error Info”タブに発生したエラー情報を表示します。
 - オーディオエンジン設定
コントロールパネルの“Advanced”タブで“ISO Extra Buffer”が設定できます。デフォルトは“Auto”でほとんどの場合はこれが最適な設定となりますが、ユーザーが手動で設定することもできます。バッファサイズが大きければ安定性も増しますが、レイテンシーも大きくなります。

既知の問題

- UR242 か UR44 を Windows 10 環境でご使用の場合、PC のスタートアップ後にハードウェアやドライバーは正常に動作しているにもかかわらず [POWER] インジケーターが点滅し続ける場合があります。このような場合には LED の点滅以外には UR の機能には問題はありません。