

# UR44C

USB AUDIO INTERFACE



**EN** *Startup Guide*

**DE** *Kurzanleitung*

**FR** *Guide de démarrage*

**ES** *Guía de inicio*

**PT** *Guia de Inicialização*

**IT** *Guida iniziale*


**RU** *Руководство по подготовке к запуску*

**ZH** *启动指南*

**KO** *시작 가이드*

**JA** *スタートアップガイド*





## Explanation of Graphical Symbols

### Explication des symboles



The lightning flash with arrowhead symbol within an equilateral triangle is intended to alert the user to the presence of uninsulated "dangerous voltage" within the product's enclosure that may be of sufficient magnitude to constitute a risk of electric shock to persons. L'éclair avec une flèche à l'intérieur d'un triangle équilatéral est destiné à attirer l'attention de l'utilisateur sur la présence d'une « tension dangereuse » non isolée à l'intérieur de l'appareil, pouvant être suffisamment élevée pour constituer un risque d'électrocution.



The exclamation point within an equilateral triangle is intended to alert the user to the presence of important operating and maintenance (servicing) instructions in the literature accompanying the product. Le point d'exclamation à l'intérieur d'un triangle équilatéral est destiné à attirer l'attention de l'utilisateur sur la présence d'instructions importantes sur l'emploi ou la maintenance (réparation) de l'appareil dans la documentation fournie.

## IMPORTANT SAFETY INSTRUCTIONS

- 1 Read these instructions.
- 2 Keep these instructions.
- 3 Heed all warnings.
- 4 Follow all instructions.
- 5 Do not use this apparatus near water.
- 6 Clean only with dry cloth.
- 7 Do not block any ventilation openings. Install in accordance with the manufacturer's instructions.
- 8 Do not install near any heat sources such as radiators, heat registers, stoves, or other apparatus (including amplifiers) that produce heat.
- 9 Do not defeat the safety purpose of the polarized or grounding-type plug. A polarized plug has two blades with one wider than the other. A grounding type plug has two blades and a third grounding prong. The wide blade or the third prong are provided for your safety. If the provided plug does not fit into your outlet, consult an electrician for replacement of the obsolete outlet.
- 10 Protect the power cord from being walked on or pinched particularly at plugs, convenience receptacles, and the point where they exit from the apparatus.
- 11 Only use attachments/accessories specified by the manufacturer.
- 12 Use only with the cart, stand, tripod, bracket, or table specified by the manufacturer, or sold with the apparatus. When a cart is used, use caution when moving the cart/apparatus combination to avoid injury from tip-over.
- 13 Unplug this apparatus during lightning storms or when unused for long periods of time.
- 14 Refer all servicing to qualified service personnel. Servicing is required when the apparatus has been damaged in any way, such as power-supply cord or plug is damaged, liquid has been spilled or objects have fallen into the apparatus, the apparatus has been exposed to rain or moisture, does not operate normally, or has been dropped.



### WARNING

TO REDUCE THE RISK OF FIRE OR ELECTRIC SHOCK, DO NOT EXPOSE THIS APPARATUS TO RAIN OR MOISTURE.

(UL60065\_03)

## PRÉCAUTIONS CONCERNANT LA SÉCURITÉ

- 1 Lire ces instructions.
- 2 Conserver ces instructions.
- 3 Tenir compte de tous les avertissements.
- 4 Suivre toutes les instructions.
- 5 Ne pas utiliser ce produit à proximité d'eau.
- 6 Nettoyer uniquement avec un chiffon propre et sec.
- 7 Ne pas bloquer les orifices de ventilation. Installer l'appareil conformément aux instructions du fabricant.
- 8 Ne pas installer l'appareil à proximité d'une source de chaleur comme un radiateur, une bouche de chaleur, un poêle ou tout autre appareil (y compris un amplificateur) produisant de la chaleur.
- 9 Ne pas modifier le système de sécurité de la fiche polarisée ou de la fiche de terre. Une fiche polarisée dispose de deux broches dont une est plus large que l'autre. Une fiche de terre dispose de deux broches et d'une troisième pour le raccordement à la terre. Cette broche plus large ou cette troisième broche est destinée à assurer la sécurité de l'utilisateur. Si la fiche équipant l'appareil n'est pas compatible avec les prises de courant disponibles, faire remplacer les prises par un électricien.
- 10 Acheminer les cordons d'alimentation de sorte qu'ils ne soient pas pénétrés ni coincés, en faisant tout spécialement attention aux fiches, prises de courant et au point de sortie de l'appareil.
- 11 Utiliser exclusivement les fixations et accessoires spécifiés par le fabricant.
- 12 Utiliser exclusivement le chariot, le stand, le trépied, le support ou la table recommandés par le fabricant ou vendus avec cet appareil. Si l'appareil est posé sur un chariot, déplacer le chariot avec précaution pour éviter tout risque de chute et de blessure.
- 13 Débrancher l'appareil en cas d'orage ou lorsqu'il doit rester hors service pendant une période prolongée.
- 14 Confier toute réparation à un personnel qualifié. Faire réparer l'appareil s'il a subi tout dommage, par exemple si la fiche ou le cordon d'alimentation est endommagé, si du liquide a coulé ou si des objets sont tombés à l'intérieur de l'appareil, si l'appareil a été exposé à la pluie ou à de l'humidité, si l'appareil ne fonctionne pas normalement ou est tombé.



### AVERTISSEMENT

POUR RÉDUIRE LES RISQUES D'INCENDIE OU DE DÉCHARGE ÉLECTRIQUE, N'EXPOSEZ PAS CET APPAREIL À LA PLUIE OU À L'HUMIDITÉ.

(UL60065\_03)

# FCC INFORMATION (U.S.A.)

## 1. IMPORTANT NOTICE: DO NOT MODIFY THIS UNIT!

This product, when installed as indicated in the instructions contained in this manual, meets FCC requirements. Modifications not expressly approved by Yamaha may void your authority, granted by the FCC, to use the product.

**2. IMPORTANT:** When connecting this product to accessories and/or another product use only high quality shielded cables. Cable/s supplied with this product **MUST** be used. Follow all installation instructions. Failure to follow instructions could void your FCC authorization to use this product in the USA.

**3. NOTE:** This product has been tested and found to comply with the requirements listed in FCC Regulations, Part 15 for Class "B" digital devices. Compliance with these requirements provides a reasonable level of assurance that your use of this product in a residential environment will not result in harmful interference with other electronic devices. This equipment generates/uses radio frequencies and, if not installed and used according to the instructions found in the users manual, may cause interference harmful to the operation of other

electronic devices. Compliance with FCC regulations does not guarantee that interference will not occur in all installations. If this product is found to be the source of interference, which can be determined by turning the unit "OFF" and "ON", please try to eliminate the problem by using one of the following measures:

Relocate either this product or the device that is being affected by the interference.

Utilize power outlets that are on different branch (circuit breaker or fuse) circuits or install AC line filter/s.

In the case of radio or TV interference, relocate/reorient the antenna. If the antenna lead-in is 300 ohm ribbon lead, change the lead-in to co-axial type cable.

If these corrective measures do not produce satisfactory results, please contact the local retailer authorized to distribute this type of product. If you can not locate the appropriate retailer, please contact Yamaha Corporation of America, Electronic Service Division, 6600 Orangethorpe Ave, Buena Park, CA90620

The above statements apply **ONLY** to those products distributed by Yamaha Corporation of America or its subsidiaries.

\* This applies only to products distributed by YAMAHA CORPORATION OF AMERICA.

(class B)

## COMPLIANCE INFORMATION STATEMENT (DECLARATION OF CONFORMITY PROCEDURE)

Responsible Party : Yamaha Corporation of America  
Address : 6600 Orangethorpe Ave., Buena Park, Calif. 90620  
Telephone : 714-522-9011  
Type of Equipment : USB AUDIO INTERFACE  
Model Name : UR44C

This device complies with Part 15 of the FCC Rules.

Operation is subject to the following two conditions:

- 1) this device may not cause harmful interference, and
- 2) this device must accept any interference received including interference that may cause undesired operation.

See user manual instructions if interference to radio reception is suspected.

\* This applies only to products distributed by YAMAHA CORPORATION OF AMERICA.

(FCC DoC)

# Contents

---

<b>Message from the development team .....</b>	<b>5</b>
<b>Package Contents .....</b>	<b>5</b>
<b>PRECAUTIONS .....</b>	<b>6</b>
Notice .....	8
Information .....	8
Precautions for the AC Adaptor .....	9
<b>Manuals .....</b>	<b>10</b>
<b>Conventions in this manual .....</b>	<b>10</b>
<b>TOOLS for UR-C .....</b>	<b>11</b>
Yamaha Steinberg USB Driver .....	11
Steinberg UR-C Applications .....	11
Basic FX Suite .....	11
<b>Preparation before using with a computer .....</b>	<b>12</b>
Installing TOOLS for UR-C .....	12
Activating Basic FX Suite .....	14
Downloading Cubase AI .....	14
<b>Preparation before using with an iOS device .....</b>	<b>15</b>
<b>Setting up the power supply .....</b>	<b>16</b>
AC Adaptor .....	16
Bus-powered .....	16

## Message from the development team

The UR44C marks the second generation of the UR series of USB Audio Interface, first introduced in 2011. This new generation represents a further evolution in the features to which we have remained committed since the release of the first model in the UR series: high-quality audio that is faithful to the source, and a reliable platform that provides stable operation even in demanding production environments.

The sound input from the special D-PRE microphone preamplifier, inherited from the beginning of the UR series, is processed at a maximum 32-bit/192 kHz resolution, and accurately captures not only the beautifully detailed sound of the performers, but also the atmosphere of the venue. Yamaha's custom-designed SSP3 DSP is also built into this model, and provides advanced routing, effects processing, and latency-free monitoring. Moreover, the driver—arguably the most important feature of an audio interface—supports USB 3.0 for stable and high-quality recording even at very low latency settings.


The UR series is continuing to evolve along with the changing needs in music production, and we take great satisfaction in knowing that this evolution will contribute to the creative efforts of our users.

The behind-the-scenes technology that has led to this evolution exists to support your creative output. With the second generation of the UR series, we sincerely hope that you find music production to be more enjoyable and rewarding.


The Steinberg Hardware Development Team

## Package Contents


The package of this product contains the following items. After opening the package, make sure that it includes everything listed below.




1 UR44C main unit




2 AC adaptor  
(PA-150B or equivalent)




3 USB 3.0 cable (3.1 Gen1, Type-C to Type-A, 1.0 m)



4 UR44C Startup Guide  
(this book)



5 CUBASE AI DOWNLOAD  
INFORMATION



6 ESSENTIAL PRODUCT LICENCE  
INFORMATION

### NOTE

The shape of the plug differs depending on locale.

# PRECAUTIONS

---

## PLEASE READ CAREFULLY BEFORE PROCEEDING

Please keep this manual in a safe place for future reference.



## WARNING

---

**Always follow the basic precautions listed below to avoid the possibility of serious injury or even death from electrical shock, short-circuiting, damages, fire or other hazards. These precautions include, but are not limited to, the following:**

### If you notice any abnormality

---

- If any of the following problems occur, immediately turn off the power switch and disconnect the electric plug from the outlet. If any of the following problems occur, immediately turn off the power of the amplifier.
  - The power cord or AC adaptor becomes frayed or damaged.
  - Unusual smells or smoke are emitted.
  - Some object, or water has been dropped into the product.
  - There is a sudden loss of sound during use of the product.
  - Cracks or other visible damage appear on the product. Then have the product inspected or repaired by qualified Yamaha service personnel.

### Power supply/AC adaptor

---

- Do not place the power cord near heat sources such as heaters or radiators, and do not excessively bend or otherwise damage the cord, place heavy objects on it, or place it in a position where anyone could walk on, trip over, or roll anything over it.
- Only use the voltage specified as correct for the product. The required voltage is printed on the name plate of the product.

- Use the specified adaptor only. Using the wrong adaptor can result in damage to the product or overheating.
- Check the electric plug periodically and remove any dirt or dust which may have accumulated on it.
- Make sure to fully insert the electric plug to prevent electric shocks or fire.
- When setting up the product, make sure that the AC outlet you are using is easily accessible. If some trouble or malfunction occurs, immediately turn off the power switch and disconnect the plug from the outlet. Even when the power switch is turned off, as long as the power cord is not unplugged from the wall AC outlet, the product will not be disconnected from the power source.
- Remove the electric plug from the outlet when the product is not to be used for extended periods of time.
- Do not touch the product or the electric plug during an electrical storm.

### Do not open

---

- This product contains no user-serviceable parts. Do not attempt to disassemble the internal parts or modify them in any way.

### Water warning/Fire warning

---

- Do not expose the product to rain, use it near water or in damp or wet conditions, or place on it any containers (such as vases, bottles or glasses) containing liquids which might spill into any openings.
- Never insert or remove an electric plug with wet hands.
- Do not place any burning items or open flames near the product, since they may cause a fire.

### Hearing loss

---

- Before connecting the product to other devices, turn off the power for all devices. Also, before turning the power of all devices on or off, make sure that all volume levels are set to the minimum. Failing to do so may result in hearing loss, electric shock, or device damage.
- When turning on the AC power in your audio system, always turn on the power amplifier LAST, to avoid hearing loss and speaker

damage. When turning the power off, the power amplifier should be turned off FIRST for the same reason.

- Do not use headphones for a long period of time at a high or uncomfortable volume level, since this can cause permanent hearing loss. If you experience any hearing loss or ringing in the ears, consult a physician.

## CAUTION

**Always follow the basic precautions listed below to avoid the possibility of physical injury to you or others, or damage to the product or other property. These precautions include, but are not limited to, the following:**

### **Power supply/AC adaptor**

- Do not cover or wrap the AC adaptor with a cloth or blanket.
- When removing the electric plug from the product or an outlet, always hold the plug itself and not the cord. Pulling by the cord can damage it.

### **Location and connection**

- Do not place the product in an unstable position where it might accidentally fall over and cause injuries.
- Keep the device out of reach of children. This product is not suitable for use in locations where children are likely to be present.
- Do not place the product in a location where it may come into contact with corrosive gases or salt air. Doing so may result in malfunction.
- Before moving the product, remove all connected cables.

### **Maintenance**

- Remove the power plug from the AC outlet when cleaning the product.

### **Handling caution**

- Do not rest your weight on the product or place heavy objects on it.

Yamaha/Steinberg cannot be held responsible for damage caused by improper use or modifications to the product, or data that is lost or destroyed.

## Notice

To avoid the possibility of malfunction/ damage to the product, damage to data, or damage to other property, follow the notices below.

### ■ Handling and maintenance

- Do not use the product in the vicinity of a TV, radio, AV equipment, mobile phone, or other electric products. Otherwise, the product, TV, or radio may generate noise.
- Do not expose the product to excessive dust or vibration, or extreme cold or heat (such as in direct sunlight, near a heater, or in a car during the day), in order to prevent the possibility of panel disfiguration, unstable operation, or damage to the internal components.
- Condensation can occur in the product due to rapid, drastic changes in ambient temperature—when the product is moved from one location to another, or air conditioning is turned on or off, for example. Using the product while condensation is present can cause damage. If there is reason to believe that condensation might have occurred, leave the product for several hours without turning on the power until the condensation has completely dried out.
- Do not place vinyl, plastic or rubber objects on the product, since this might discolor the panel.
- When cleaning the product, use a dry and soft cloth. Do not use paint thinners, solvents, cleaning fluids, or chemical-impregnated wiping cloths.
- To avoid generating unwanted noise, make sure there is adequate distance between the AC power adaptor and the product.

### ■ Connectors

- XLR-type connectors are wired as follows (IEC60268 standard): pin 1: ground, pin 2: hot (+), and pin 3: cold (-).

## Information

### ■ About copyrights

- This manual is the exclusive copyrights of Yamaha Corporation.
- Copying of the software or reproduction of this manual in whole or in part by any means is expressly forbidden without the written consent of the manufacturer.
- This product incorporates and bundles computer programs and contents in which Steinberg Media Technologies GmbH and Yamaha Corporation own copyrights or with respect to which it has license to use others' copyrights. Such copyrighted materials include, without limitation, all computer software, style files, MIDI files, WAVE data, musical scores and sound recordings. Any unauthorized use of such programs and contents outside of personal use is not permitted under relevant laws. Any violation of copyright has legal consequences. **DON'T MAKE, DISTRIBUTE OR USE ILLEGAL COPIES.**

### ■ About this manual

- The illustrations and LCD screens as shown in this manual are for instructional purposes only.
- Steinberg Media Technologies GmbH and Yamaha Corporation make no representations or warranties with regard to the use of the software and documentation and cannot be held responsible for the results of the use of this manual and the software.
- Steinberg, Cubase and Cubasis are registered trademarks of Steinberg Media Technologies GmbH.
- Windows is a registered trademark of Microsoft® Corporation in the United States and other countries.
- Apple, Mac, iPad, iPhone, and Lightning are trademarks of Apple Inc., registered in the U.S. and other countries.
- IOS is a trademark or registered trademark of Cisco in the U.S. and other countries and is used under license.



- The company names and product names in this manual are the trademarks or registered trademarks of their respective companies.
- Software may be revised and updated without prior notice.

#### ■ About disposal

- This product contains recyclable components. When disposing of this product, please contact the appropriate local authorities.

The model number, serial number, power requirements, etc., may be found on or near the name plate, which is at the bottom of the unit. You should note this serial number in the space provided below and retain this manual as a permanent record of your purchase to aid identification in the event of theft.

**Model No.**

---

**Serial No.**

---

(bottom\_en\_01)


## Precautions for the AC Adaptor

### WARNING

- Only use the included AC adaptor (or an equivalent recommended by Yamaha). Using the wrong adaptor can result in damage to the device or overheating.
- Indoor use only. Do not use in any wet environments.
- Remove the electric plug from the outlet when the device is not used for extended periods of time, or during electrical storms.

#### If the plug is accidentally removed from the AC adaptor

Making sure not to touch the metallic section, slide the plug as indicated, then push it in completely until you hear the click sound.



### WARNING

- Make sure to keep the plug attached to the AC adaptor. Using the plug alone can cause electric shock or fire.
- Never touch the metallic section when attaching the plug. To avoid electric shock, short circuit or damage, also be careful that there is no dust between the AC adaptor and plug.

#### NOTE

The shape of the plug differs depending on locale.

## Manuals

---

The UR44C has the following two separate manuals.

### Startup Guide (this book)

Read this manual when setting up the device. After finishing the setup as indicated in this manual, read the Operation Manual.

### Operation Manual (PDF)

Read through this manual to understand how to use the features of the product. You can download the Operation Manual from the Steinberg website:

<http://www.steinberg.net/hardwaredownloads>

#### NOTE

To view PDF files, you need to install Adobe Reader on your computer. You can download the latest version at the following website.

<https://www.adobe.com/>

## Conventions in this manual

---

### Windows or Mac

When the procedures or explanations are specific to only one of the platforms, Windows or Mac, this is properly indicated in the manual. When the platforms do not appear, procedures or explanations are for both Windows and Mac. This manual predominantly uses screenshots of Windows. However, Mac screenshots are used when instructions of the function apply only to the Mac.

### Cubase series

The phrase "Cubase" in this manual applies to all Cubase programs and versions (except Cubase LE). If a specific version is indicated, the version is described in the text. This manual uses screenshots of Cubase Pro 10 series. If you are using another version of Cubase, the actual screenshots might not be the same. For details, refer to the Cubase manuals.

### Cubasis series

This manual uses screenshots of Cubasis 2. If you are using another version of Cubasis, the actual screen shots might not be the same.

### Procedures

An arrow "→" is shown for some procedures in the manual. For example, the string [Studio] → [Studio Setup] → [Control Panel] indicates that you should perform the procedures in the following order.

1. Click the [Studio] menu.
2. Select the [Studio Setup] option.
3. Click the [Control Panel] button.

### Version information

The letters "x.x.x" and "x.xx" indicate the version number.

## **TOOLS for UR-C**

The software TOOLS for UR-C is necessary for proper connection and use of the device with a computer. Make sure to install it before initially using the device (page 12). You will need to download TOOLS for UR-C beforehand from the Steinberg website below.

<http://www.steinberg.net/hardwaredownloads>

When you install the TOOLS for UR-C, the following three software programs will be installed.

### **NOTE**

- TOOLS for UR-C does not support iOS devices.
- For the latest information on TOOLS for UR-C, see the Steinberg website.

## **Yamaha Steinberg USB Driver**

This software allows communication between the device and a computer.

## **Steinberg UR-C Applications**

This software allows setting the parameters of the device from a computer or using the Link function between the device and Cubase series software. The software consists of the following two components.

### **• Steinberg dspMixFx UR-C**

This editing software lets you set the device when using the device independently, or when using it with a DAW (Digital Audio Workstation) software other than Cubase series. You can use Cubase and dspMixFx UR-C at the same time.

### **• Steinberg UR-C Extension**

This software allows you to link the device with Cubase series (for versions which supports the link function). To use this link function, see the Steinberg web site below.

<https://www.steinberg.net/>

## **Basic FX Suite**

Basic FX Suite is software consisting of Plug-ins of various effects and sound processing developed by Yamaha, some of which fully utilize modeling technology. When you install the Basic FX Suite, the following three software programs will be installed.

### **NOTE**

AU (Audio Unit) Plug-ins are additionally available, as well as VST Plug-ins, for use with a Mac.

### **• Sweet Spot Morphing Channel Strip**

This processing effect is a multi effect that features a compressor and equalizer.

### **• REV-X**

This processing effect is a digital reverb platform developed by Yamaha for professional audio devices.

### **• Guitar Amp Classics**

This processing effect features guitar amp simulations developed by Yamaha that fully utilize modeling technology.

## Preparation before using with a computer

The following three setup procedures are required before you can use the device with a computer.

- Installing TOOLS for UR-C
- Activating Basic FX Suite
- Downloading Cubase AI (DAW)

### Installing TOOLS for UR-C

Download TOOLS for UR-C beforehand from the Steinberg website. Follow the steps below to install the TOOLS for UR-C.

#### NOTE

- You are only permitted to use this software pursuant to the terms and conditions of the "License Agreement" shown during the installation.
- Future upgrades of application and system software and any changes in specifications and functions will be announced at the following website.  
<https://www.steinberg.net/>
- The eLicenser Control Center (eLCC) for controlling the product license is installed at the same time.

### Windows

- 1. Disconnect all USB devices other than the mouse and keyboard from the computer.**
- 2. Start the computer and log on to the Administrator account.**

Exit any open applications and close all open windows.
- 3. Extract the previously downloaded TOOLS for UR-C.**

- 4. Double click the [setup.exe] file in the extracted folder to start the installation.**
- 5. Follow the on-screen instructions to install the software.**

#### NOTE


- While installing the software, the "eLicenser Control Center" installation message appears. Follow the onscreen instructions to install the software.
- You can select the desired software to be installed on the installation screen.
  - Yamaha Steinberg USB Driver
  - Steinberg UR-C Applications
  - Basic FX Suite (VST3 Plug-ins)

- 6. When installation has been completed, click [Finish].**

If a window requiring you to restart your computer appears, follow the onscreen instructions and restart the computer.

### Confirmation of Installation

- 7. Move the [POWER SOURCE] switch to the right and then insert the plug of the included AC adapter into the DC IN [12V] jack on the device.**



- 8. Connect the device directly to the computer by using the included USB cable.**

Make sure not to connect it to a USB hub.

**9. Open the [Device Manager] window as follows.**

[Control Panel] → ([Hardware and Sound]) → [Device Manager]

**10. Click on the [>] mark next to “Sound, video and game controllers.”**

Confirm that the device name is listed.

Installation of the TOOLS for UR-C is now complete.

## Mac

**1. Disconnect all USB devices other than the mouse and keyboard from the computer.**

**2. Start the computer and log in to the Administrator account.**

Exit any open applications and close all open windows.

**3. Extract the previously downloaded TOOLS for UR-C.**

**4. Double click the [TOOLS for UR-C V\*\*.pkg] file in the extracted folder to start the installation.**

The characters \*\*\* represent the version number.

**5. Follow the on-screen instructions to install the software.**

### NOTE


- While installing the software, the “eLicenser Control Center” installation message appears. Follow the onscreen instructions to install the software.
- You can select the desired software to be installed on the installation screen.
  - Yamaha Steinberg USB Driver
  - Steinberg UR-C Applications

- Basic FX Suite (VST3/AU Plug-ins)

**6. When installation has been completed, click [Restart] or [Close].**

## Confirmation of Installation

**7. Move the [POWER SOURCE] switch to the right and then insert the plug of the included AC adapter into the DC IN [12V] jack on the device.**



**8. Connect the device directly to the computer by using the included USB cable.**

Make sure not to connect it to a USB hub.

**9. Open the “Audio MIDI Setup” window as follows.**

[Applications] → [Utilities] → [Audio MIDI Setup]

**10. Confirm that the device name is listed in the left column.**

Installation of the TOOLS for UR-C is now complete.

## Activating Basic FX Suite

To use the Basic FX Suite programs which are installed in “Installing TOOLS for UR-C,” you will need to download the licenses for them via the Internet. Use the Activation Code provided on the ESSENTIAL PRODUCT LICENSE INFORMATION.

### 1. Launch the “eLicenser Control Center” as follows.

#### Windows

[All Programs] or [All apps] →  
[eLicenser] → [eLicenser Control Center]

#### Mac

[Applications] → [eLicenser Control Center]

### 2. Click [Enter Activation Code].

### 3. Enter the Activation Code described on the included ESSENTIAL PRODUCT LICENSE INFORMATION.

### 4. Follow the on-screen instructions to download the licenses.

#### NOTE

If you connect a USB-eLicenser (USB protection device) to your computer, a window requiring you to select the destination of the license appears. Follow the on-screen instructions to select the device. Keep in mind that the license saved in the USB-eLicenser cannot be transferred to the Soft-eLicenser.

## Downloading Cubase AI

We are offering Cubase AI as a free download via our website, specifically for customers who have purchased the UR44C. Cubase AI is software for music production that allows you to record, play, and edit sounds on a computer. In order to download the software, you'll need to first create a MySteinberg account on the Steinberg website. For the latest information, see the Steinberg website below.

<http://www.steinberg.net/getcubaseai/>

#### NOTE

A valid “Download access code” is required for Cubase AI download. It is printed on the included CUBASE AI DOWNLOAD INFORMATION.

The setup is now complete.

For detailed instructions and information on the functions of the product, read the operation manual.

## Preparation before using with an iOS device

---

The following preparations are required before you can use the device with an iOS device.

### Apple accessories

These may be necessary for connecting the device to an iOS device.

- **iOS devices equipped with Type-C port**

USB-C charge cable in the Apple product box.

- **iOS devices not equipped with Type-C port**

Lightning to USB Camera Adapter (optional)  
or

Lightning to USB 3 Camera Adapter (optional)

### Downloading Steinberg dspMixFx UR-C (mixing app)

Download from the App store.

### Downloading DAW app as necessary

Download from the App Store.

#### NOTE

- Installing the TOOLS for UR-C is not necessary when connecting the device to an iOS device.

- For the latest information on compatible iOS devices, refer to the Steinberg Website below.  
<https://www.steinberg.net/>

The setup is now complete.


For detailed instructions and information on the functions of the product, read the operation manual. In the operation manual, you can refer to the basic instructions for operating with Cubasis (an iPad app sold by Apple) as an example.

# Setting up the power supply


Power can be supplied via the AC adaptor or a USB cable (bus-powered).

## AC Adaptor

1. Move the [POWER SOURCE] switch on the rear panel to the right.




2. Insert the plug of the AC adaptor into the DC IN [12V] jack on the rear panel.
3. Insert the plug of the AC adaptor into a proper AC outlet.
4. The POWER indicator on the front panel lights when the power is turned on.




## Bus-powered

For buspowered supply, you will need the commercially available USB 3.1 Type-C to Type-C cable (optional).

1. Move the [POWER SOURCE] switch on the rear panel to the left.



2. Connect the USB Type-C jack on a computer to the [USB 3.0] jack with USB 3.1 Type-C to Type-C cable (optional).
3. The POWER indicator on the front panel lights when the power is turned on.



### WARNING

Before turning the power of all devices on or off, set all volume levels to minimum. Failing to do so may result in hearing loss, electric shock, or device damage.

### NOTICE

- To avoid generating unwanted noise, make sure there is adequate distance between the power adaptor and the device.



### **Information for users on collection and disposal of old equipment:**



This symbol on the products, packaging, and/or accompanying documents means that used electrical and electronic products should not be mixed with general household waste. For proper treatment, recovery and recycling of old products, please take them to applicable collection points, in accordance with your national legislation.

By disposing of these products correctly, you will help to save valuable resources and prevent any potential negative effects on human health and the environment which could otherwise arise from inappropriate waste handling.

For more information about collection and recycling of old products, please contact your local municipality, your waste disposal service or the point of sale where you purchased the items.

### **For business users in the European Union:**

If you wish to discard electrical and electronic equipment, please contact your dealer or supplier for further information.

### **Information on Disposal in other Countries outside the European Union:**

This symbol is only valid in the European Union. If you wish to discard these items, please contact your local authorities or dealer and ask for the correct method of disposal.

► **Warranty Terms and Conditions**

available as printed PDF file at

**[www.steinberg.net/warranty](http://www.steinberg.net/warranty)**

The Warranty Terms and Conditions available as printed PDF file at [www.steinberg.net/warranty](http://www.steinberg.net/warranty) apply only for countries of the European Economic Area (EEA) and Switzerland.

► **Gewährleistungsbestimmungen**

finden Sie als druckbare PDF Datei unter

**[www.steinberg.de/warranty](http://www.steinberg.de/warranty)**

Die Gewährleistungsbestimmungen in Schriftform sind als PDF-Datei unter [www.steinberg.de/warranty](http://www.steinberg.de/warranty) erhältlich und gelten nur für den Europäischen Wirtschaftsraum (EWR) und die Schweiz.

► **Les conditions de garantie**

se trouvent dans le document PDF imprimable sous

**[www.steinberg.net/warranty](http://www.steinberg.net/warranty)**

Les conditions de garantie disponibles au format PDF à la page [www.steinberg.net/warranty](http://www.steinberg.net/warranty) s'appliquent uniquement aux pays de l'Espace économique européen (EEE) et à la Suisse.

► **Las condiciones de garantía**

se encuentran en el documento PDF en

**[www.steinberg.net/warranty](http://www.steinberg.net/warranty)**

Los términos y condiciones de la garantía como archivo PDF para su impresión en [www.steinberg.net/warranty](http://www.steinberg.net/warranty) sólo están disponible en países del Espacio Económico Europeo (EEE) y Suiza.

► **Termos e condições de garantia**

arquivo PDF disponível no endereço

**[www.steinberg.net/warranty](http://www.steinberg.net/warranty)**

O arquivo PDF com os Termos e condições de garantia disponibilizado no endereço [www.steinberg.net/warranty](http://www.steinberg.net/warranty) aplica-se somente aos países da Área Económica Europeia (AEE) e à Suíça.

► **Termini e Condizioni di Garanzia**

disponibili su file PDF stampabile all'indirizzo web

**[www.steinberg.net/warranty](http://www.steinberg.net/warranty)**

termini e le condizioni della garanzia, disponibili in formato PDF all'indirizzo [www.steinberg.net/warranty](http://www.steinberg.net/warranty), sono validi soltanto per i paesi dell'Area Economica Europea (EEA) e per la Svizzera.

## List of distributors

If you need support or further product information please contact the distributor in your country. A list of distributors is available at this website.  
For assistance in determining who to contact, please contact "Headquarter SMTG."

EN

Wenn Sie Unterstützung oder weitere Produktinformationen benötigen, wenden Sie sich bitte an den Vertrieb in Ihrem Land.  
Eine Liste der Vertriebspartner finden Sie auf dieser Website.  
Wenn Sie Hilfe benötigen, an wen Sie sich wenden sollten, kontaktieren Sie bitte „Headquarter SMTG“.

DE

Pour toute demande d'assistance ou d'information supplémentaire sur les produits, veuillez contacter le distributeur agréé dans votre pays.  
La liste des distributeurs agréés est disponible sur le site Web suivant.  
Pour obtenir de l'aide sur les ressources à contacter, adressez-vous au « Siège de SMTG ».

FR

Para solicitar asistencia o más información sobre el producto, póngase en contacto con el distribuidor de su país.  
Encontrará una lista de distribuidores en el siguiente sitio web.  
Para consultas sobre el contacto adecuado, diríjase a "Headquarter SMTG."

ES

Se você precisar de suporte ou de mais informações sobre o produto, entre em contato com o distribuidor no seu país.  
Há uma lista de distribuidores disponível neste site.  
Para receber ajuda para determinar com quem entrar em contato, fale com a "Sede da SMTG".

PT

Per ottenere assistenza o avere ulteriori informazioni sul prodotto, contattare il distributore locale.  
L'elenco dei distributori è disponibile sul sito Web al seguente indirizzo.  
Per individuare il distributore da contattare, rivolgersi alla sede centrale SMTG.

IT

Если вам необходима техническая поддержка или дополнительные сведения о продуктах, обратитесь к дистрибьютору в вашей стране.  
Список дистрибьюторов можно найти на этом веб-сайте.  
Чтобы узнать, к кому следует обращаться, свяжитесь с центральным офисом SMTG.

RU

如需更多支持和深层产品信息,请联系您所在国家的代理商。  
代理商列表请浏览下列网址。  
如需帮助决定联系哪方代理商,请联系" SMTG总公司"。

ZH

지원 또는 추가 제품 정보가 필요한 경우 해당 국가의 판매업체에 문의하십시오.  
판매업체 목록은 다음 웹사이트에서 이용할 수 있습니다.  
문의 판매업체를 결정하는 데 도움이 필요한 경우 "SMTG 본사"에 문의하십시오.

KO

<https://www.steinberg.net/en/company/distributor.html>

**HEAD OFFICE: Steinberg Media Technologies GmbH**

Beim Strohhause 31, 20097 Hamburg, Germany Tel: +49-(0)40-210 35 0

雅马哈乐器音响（中国）投资有限公司

上海市静安区新闻路 1818 号云和大厦 2 楼

客户服务热线：4000517700

公司网址：<https://www.yamaha.com.cn>

厂名：雅马哈电子（苏州）有限公司

厂址：江苏省苏州市苏州新区鹿山路 18 号

Steinberg Website  
<https://www.steinberg.net/>

Manual Development Group  
© 2019 Yamaha Corporation

Published 06/2019  
2019 年 6 月发行  
MWES-A1

VAD5080

